



ATCOM[®] Hybrid Card AX-2G4A

Product Guide

Version: 2.0

Written by Robert.Ao

Dec 5th, 2011

Content

CONTACT ATCOM	2
CHAPTER 1 THE INTRODUCTION OF AX-2G4A.....	3
CHAPTER 2 HARDWARE INTRODUCTION	5
CHAPTER 3 SOFTWARE INSTALLATION.....	7
CHAPTER 4 SOFTWARE CONFIGURATION	9
CHAPTER 5 TEST	13
CHAPTER 6 SENDING AND RECEIVING SMS	16
CHAPTER 7 REFERENCE	18

Contact ATCOM

The Introduction of ATCOM

Founded in 1998, ATCOM technology has been always endeavoring in the R&D and manufacturing of the internet communication terminals. The product line of ATCOM includes IP Phone, USB Phone, IP PBX, VoIP gateway and Asterisk Card.

Contact sales:

Address	District C, east of 2nd floor, #3, Crown industry buildings, Chegongmiao Industry area, Futian district, Shenzhen, China
Tel	+(86)755-23487618
Fax	+(86)755-23485319
E-mail	sales@atcomemail.com

Contact Technical Support:

Tel	+(86)755-23481119
E-mail	Support@atcomemail.com

Website address: <http://www.atcom.cn/>

ATCOM Wiki Website: http://www.openippbx.org/index.php?title=Main_Page

Download Center: <http://www.atcom.cn/download.html>

Chapter 1 the Introduction of AX-2G4A

Overview of the AX-2G4A

AX-2G4A Asterisk card is a hybrid card, which support two GSM channels and 4 FXO/FXS analog ports. Using AX-2G4A, open source Asterisk PBX and stand alone PC, users can create their SOHO telephony solution which includes all the sophisticated features of traditional PBX, and extended features in IP PBX, such as voicemail, call transfer, call park, call pick up, call forward, bulk SMS sending, SMS receiving and so on.

Features

- Two GSM channels and four analog ports
- Bulk SMS sending
- SMS receiving and storage
- Multi-language for SMS content
- IMEI changeable
- PIN-Number unlock for the SIM card
- Monitor GSM signal strength by command and LEDs
- Monitor communication status by command line
- Send SMS by Asterisk CLI, and dial-plan
- Detect accurately when the called party answers the call
- GSM quadband frequency(850/900/1800/1900MHz)
- DTMF detection
- Suitable for 3.3 volts and 5.0 volts 32 bit PCI slots
- PCI slot or 4-pin connector for power feeding
- Elastix, Trixbox (not support now, it will be supported two weeks later)

Applications

- GSM and analog connectivity for PBX
- Mobile and analog PBX
- GSM and analog VoIP gateway
- SMS gateway
- GSM callback services
- Billing system

Hardware Requirement

- 500-Mhz Pentium III
- 64MB RAM
- 3.3V or 5V PCI 2.2 slot


Measurement and Weight

Inner box	221 * 142 * 62mm
G.W./unit	0.25kg
Card Size	174mm *104 mm

Package

Item	Quantity
AX-2G4A mother board	1
GSM module (GX01)	1-2
Dual ports analog module	1-2

Chapter 2 Hardware Introduction



GX01: GSM module, one GX01 supports one GSM channel.

AX210S: FXS module, it supports two FXS ports.

AX210X: FXO module, it supports two FXO ports.

Slot1: A slot for plugging GX01, it is the first channel of the card.

Slot2: A slot for plugging GX01, it is the second channel of the card.

Slot3: A slot for plugging FXS/FXO module, it is the third and fourth channels of the card.

Slot4: A slot for plugging FXS/FXO module, it is the fifth and sixth channels of the card.

CON1: 4 pin power connector.

SW100: Used for selecting the way of power feeding, set it to 1 ON and 2 OFF, the CON1 provide the power for the card; set it to 1 OFF and 2 ON, the PCI slot provides the power for the card. If the FXS port is used, the card must be provided power by the CON1. To ensure the enough power feeding, user should choose the CON1 to provide power for the card, and the SW100 is set to 1 ON and 2 OFF by default.

Hole: used for fixing the line which connect the GX01 to antenna.

Antenna: the antenna in the picture above is omnidirectional, the model is TS01

Attention: In order to enhance the GSM signal in some hard environment, except the Antenna in the illustration above, ATCOM can also provide one other type of antenna(TL01) which has long cable(about one meter long) and can be connected to outside.

RJ45: Used for connecting a splitter to the card, the splitter supports four RJ11 ports and one RJ45 port.

LED3: Used for checking if the FXS/FXO module is detected or not. When the FXS/FXO ports are detected correctly, the LED3 will be on.

LED11: When the channel 1 is in communication status, LED11 will be green steady.

LED12: Network status indicator of SIM card of the first channel. When the SIM card is searching network, the LED12 will blink fast; when the SIM card has found the GSM network and registered successfully, the LED12 will flip at lower frequency.

LED21: When the channel 2 is in communication status, LED21 will be green steady.

LED22: Network status indicator of SIM card of the second channel. When the SIM card is searching network, the LED22 will blink fast; when the SIM card has found the GSM network and registered successfully, the LED22 will flip at lower frequency.

Button: used for turning off the GX01.

Chapter 3 Software Installation

Test Environment:

dahdi-linux-2.3.0.4 (download from ATCOM website)
dahdi-tools-2.3.0.4
asterisk-1.6.2.6.4 (download from ATCOM website)
centos 5.6 (kernel version: 2.6.18-238.el5)
AX-2G4A+2*GX01+1*AX210S+1*AX210X

After inserting the card into your PCI slot and boot your server, please use the “lspci” command to check the PCI bus compatibility. From the correct output, you can see the following line:

```
-----  
01:01.0 Communication controller: Tiger Jet Network Inc. Tiger3XX Modem/ISDN interface  
-----
```

A Tiger Jet device will be found, if you can not see the **Tiger Jet** device, please poweroff your server and try another PCI slot, if it still does not help, you have to check the compatibility issue between the card and your PCI bus.

1. To install asterisk and dahdi, we have to use “yum” command to install the following prerequisite packages:
bison bison-devel zlib zlib-devel openssl openssl-devel gnutls-devel gcc gcc-c++

2. Download dahdi-linux, dahdi-tools, and asterisk
Attention: please download dahdi-linux and asterisk from ATCOM website, because ATCOM has modified the source code for AX-2G4A.

```
[root@localhost src]#
```

```
wget
```

```
http://chinavoipsupply.com:8080/downloads/TelephonyCard/drivers/AX2G4A\_AX4G/asterisk-1.6.2.6.4.tar.gz
```

```
[root@localhost src]#
```

```
wget
```

```
http://chinavoipsupply.com:8080/downloads/TelephonyCard/drivers/AX2G4A\_AX4G/dahdi-linux-2.3.0.4.tar.gz
```

```
[root@localhost src]#
```

```
wget
```

```
http://chinavoipsupply.com:8080/downloads/TelephonyCard/drivers/AX2G4A\_AX4G/dahdi-tools-2.3.0.4.tar.gz
```

3. Install dahdi-linux and dahdi-tools
Install dahdi-linux

- 1) [root@localhost src]# tar -xvzf dahdi-linux-2.3.0.4.tar.gz
- 2) [root@localhost dahdi-linux-2.3.0]# make
- 3) [root@localhost dahdi-linux-2.3.0]# make install

Install dahdi-tools

- 1) [root@localhost src]# tar -xvzf dahdi-tools-2.3.0.4.tar.gz
- 2) [root@localhost dahdi-tools-2.3.0]# ./configure
- 3) [root@localhost dahdi-tools-2.3.0]# make
- 4) [root@localhost dahdi-tools-2.3.0]# make install
- 5) [root@localhost dahdi-tools-2.3.0]# make config

4. Install asterisk

- 1) [root@localhost src]# tar -xvzf asterisk-1.6.2.6.4.tar.gz
- 2) [root@localhost asterisk-1.6.2.6]# ./configure
- 3) [root@localhost asterisk-1.6.2.6]# make
- 4) [root@localhost asterisk-1.6.2.6]# make install
- 5) [root@localhost asterisk-1.6.2.6]# make samples

Chapter 4 Software Configuration

1. Please check if the AX-2G4A driver has been loaded successfully, run `cat /proc/interrupts` command and you should see one line with `ax4g/ax2g4a`:

```
20: 2310670 2218516 IO-APIC-fasteoi ax4g/ax2g4a
```

If you can not see `ax4g/ax2g4a`, you can try to poweroff your server and replug AX-2G4A into another PCI slot.

2. Please run the “`dahdi_genconf`” command to configure the `/etc/dahdi/system.conf` file and generate `/etc/asterisk/dahdi-channels.conf` file.

```
[root@localhost ~]# dahdi_genconf
```

It does not show any output if `dahdi_genconf` runs successfully.

After running `dahdi_genconf` successfully, the `system.conf` file will get the following configuration:

`/etc/dahdi/system.conf`:

```
# Autogenerated by /usr/sbin/dahdi_genconf on Thu Jul 1 11:33:13 2010
# If you edit this file and execute /usr/sbin/dahdi_genconf again,
# your manual changes will be LOST.
# Dahdi Configuration File
# This file is parsed by the Dahdi Configurator, dahdi_cfg
# Span 1: WCTDM/6 "ATCOM AX4G/AX2G4A Board 7" (MASTER)
fxsks=1
echocanceller=mg2,1
fxsks=2
echocanceller=mg2,2
fxsks=3
echocanceller=mg2,3
fxsks=4
echocanceller=mg2,4
fxoks=5
echocanceller=mg2,5
fxoks=6
echocanceller=mg2,6

# Global data
loadzone      = us
defaultzone   = us
```

After running dahdi_genconf successfully, the dahdi-channels.conf file will get the following configuration:

```
; Span 1: WCTDM/6 "ATCOM AX4G/AX2G4A Board 7" (MASTER)
```

```
::: line="1 WCTDM/6/0 FXSKS (In use) (SWEC: MG2)"
```

```
signalling=fxs_ks
```

```
callerid=asreceived
```

```
group=0
```

```
context=from-pstn
```

```
channel => 1
```

```
callerid=
```

```
group=
```

```
context=default
```

```
::: line="2 WCTDM/6/1 FXSKS (In use) (SWEC: MG2)"
```

```
pinnum=1234
```

```
signalling=fxs_ks
```

```
callerid=asreceived
```

```
group=0
```

```
context=from-pstn
```

```
channel => 2
```

```
callerid=
```

```
group=
```

```
context=default
```

```
::: line="3 WCTDM/6/2 FXSKS (In use) (SWEC: MG2)"
```

```
signalling=fxs_ks
```

```
callerid=asreceived
```

```
group=0
```

```
context=from-pstn
```

```
channel => 3
```

```
callerid=
```

```
group=
```

```
context=default
```

```
::: line="4 WCTDM/6/3 FXSKS (In use) (SWEC: MG2)"
```

```
signalling=fxs_ks
```

```
callerid=asreceived
```

```
group=0
```

```
context=from-pstn
```

```
channel => 4
```

```
callerid=
```

```
group=
```

```
context=default
```

```
;;; line="5 WCTDM/6/4 FXOKS (In use) (SWEC: MG2)"  
signalling=fxo_ks  
callerid="Channel 5" <4005>  
mailbox=4005  
group=5  
context=from-internal  
channel => 5  
callerid=  
mailbox=  
group=  
context=default
```

```
;;; line="6 WCTDM/6/5 FXOKS (In use) (SWEC: MG2)"  
signalling=fxo_ks  
callerid="Channel 6" <4006>  
mailbox=4006  
group=5  
context=from-internal  
channel => 6  
callerid=  
mailbox=  
group=  
context=default
```

- Please run `dahdi_cfg -vv` command.

```
[root@localhost asterisk]# dahdi_cfg -vvvvvvvvvv
DAHDI Tools Version - 2.3.0
```

DAHDI Version: 2.3.0

Echo Cancellor(s): MG2

Configuration

=====

Channel map:

Channel 01: FXS Kewlstart (Default) (Echo Canceler: mg2) (Slaves: 01)

Channel 02: FXS Kewlstart (Default) (Echo Canceler: mg2) (Slaves: 02)

Channel 03: FXS Kewlstart (Default) (Echo Canceler: mg2) (Slaves: 03)

Channel 04: FXS Kewlstart (Default) (Echo Canceler: mg2) (Slaves: 04)

Channel 05: FXO Kewlstart (Default) (Echo Canceler: mg2) (Slaves: 05)

Channel 06: FXO Kewlstart (Default) (Echo Canceler: mg2) (Slaves: 06)

6 channels to configure.

Setting echocan for channel 1 to mg2

Setting echocan for channel 2 to mg2

Setting echocan for channel 3 to mg2

Setting echocan for channel 4 to mg2

Setting echocan for channel 5 to mg2

Setting echocan for channel 6 to mg2

- Please add the following line at the bottom of the `chan_dahdi.conf` file:

```
#include dahdi-channels.conf
```

- Please run asterisk with the following command:

```
asterisk -vvgc
```

```
reload
```

- Please run `dahdi show channels` command

You should see 6 channels as the following:

```
localhost*CLI> dahdi show channels
```

Chan Extension	Context	Language	MOH Interpret	State
pseudo	default		default	In Service
1	from-pstn		default	In Service
2	from-pstn		default	In Service
3	from-pstn		default	In Service
4	from-pstn		default	In Service
5	from-internal		default	In Service
6	from-internal		default	In Service

```
localhost*CLI>
```

Chapter 5 Test

1. Please check the status of the cell phone card plugged in the AX-2G4A.

Please type the following command three times, the result of the third time is correct:

cat /proc/dahdi/ax4g_sta_card_1

You can get one line with the following information:

S0:4, S1:4, S2:0, S3:0

The S0, S1 stand for the two modules on the AX-2G4A orderly, and different numbers behind colon stand for different status of SIM card.

a: it means that the cell phone card is sending SMS.

1: it means that the module2 is powered off.

2: it means that the cell phone card is still searching for GSM network.

3: it means that the cell phone card has registered successfully before, but now it failed.

4: it means that the cell phone card has found GSM network successfully, and it is in idle status (not used by calling or sending SMS).

5: it means that after a communication, one side hangs up the phone, but the other side has not hang up.

6: it means that the cell phone card is dialing-out.

7: it means that somebody from outside is calling the channel, but no extension answers the phone, the extension is ringing.

8: it means that an extension answers an incoming call, but the communication has not yet established, at this moment, the called party hangs up, then the caller do not need to be paid for this call, because this call has not been established really.

9: it means that the channel is in communication status, and the call has been established really.

2. Please check the network signal of the cell phone card plugged in the AX-2G4A, type the following command three times, the result of the third time is correct:

cat /proc/dahdi/GSM_signal_card_1

you can get one line with the following information:

SQ0 = 31, SQ1 = 30, SQ2 = 0, SQ3 = 0

The SQ0, SQ1 stand for the two modules on the AX-2G4A orderly, and different numbers behind equality sign stand for the network signal of the cell phone card, the numbers 0 and 99 mean no signal, for other numbers, the bigger the number is, the stronger the signal is.

3. Check when the called party answers the call, when you dial-out through AX-2G4A.

Please use **dmesg** command to detect if the called party answers the call when you dial-out through AX-2G/4A, if the called party has answered the call, after running **dmesg** command, you can get one line with **GX PR**, X stands for the channel number. This feature will help customer to do billing accurately.

4. Use the **dmesg** command to check your GX01 version:

```
[root@localhost ~]# dmesg
wctdm_init_GSM CARD:0
```

```
VoiceGSM System:0a
```

```
Module 0: Installed -- AUTO GSM(version 0x46)
```

```
wctdm_init_GSM CARD:1
```

```
VoiceGSM System:0a
```

```
Module 1: Installed -- AUTO GSM(version 0x46)
```

Notice: only the GX01 0x41 and above version support bulk SMS sending, multi-language for SMS content and Pin number unlock; only the GX01 0x46 and above version support SMS receiving.

5. Input PIN-Number for the SIM card in `/etc/asterisk/dahdi-channels.conf` file, add the following red line:

```
;;; line="2 WCTDM/6/1 FXSKS (In use) (SWEC: MG2)"
```

```
pinnum=1234
```

```
signalling=fxs_ks
```

```
callerid=asreceived
```

```
group=0
```

```
context=from-pstn
```

```
channel => 2
```

After setting, please restart asterisk to make the setting effective.

6. Please use the following command to read your IMEI number of GX01:

```
[root@localhost ~]# cat /proc/dahdi/imei_read_1
```

```
IMEI0: 355842020258444, IMEI1: 355842020187437, IMEI2: , IMEI3:
```

7. Please start asterisk, then use the following command to change IMEI, 1 stands for the channel number, and 355842020257974 stands for the IMEI number which you want to use.

```
localhost*CLI> gsm set imei 1 355842020257974
```

```
gsm set imei cardnum=1 value=355842020257974
```

```
gsm set imei ok
```

Edit a dial-plan, and use AX-2G4A to make outgoing calls and get incoming calls.

8. Please edit a dial-plan in `extensions.conf` file, you can refer to the following dial-plan:

```
[from-internal]
```

```
exten=>_1.,1,Dial(dahdi/1/${EXTEN:1})          Dial-out via GSM channels
```

```
exten=>_1.,2,Hangup()
```

```
exten=>_2.,1,Dial(dahdi/2/${EXTEN:1})
```

```
exten=>_2.,2,Hangup()
```

```
exten=>_3.,1,Dial(dahdi/3/${EXTEN:1})          Dial-out via FXO ports
```

```
exten=>_3.,2,Hangup()
```

```
exten=>_4.,1,Dial(dahdi/4/${EXTEN:1})
```

```
exten=>_4.,2,Hangup()
```

```
[from-pstn]
exten=>s,1,Answer()
exten=>s,2,Dial(sip/500)
exten=>s,3,hangup()
```

9. Use a registered sip phone to make an outgoing call, according to the dial-plan above, if you want to make the outgoing call through the first channel, you have to add a prefix “1” when you dial out, if you want to make the outgoing call through the second channel, you have to add a prefix “2”. Here, the destination number is 15128731752, so dialing 115128731752, then you can get the following output from asterisk CLI:

```
-----
*CLI> == Using SIP RTP CoS mark 5
--Executing [115128731752@from-internal:1] Dial("SIP/500-00000003",
"dahdi/1/15128731752") in new stack
-- Called 1/15128731752
-- DAHDI/1-1 answered SIP/500-00000003
-----
```

The called party rings, and pick up the phone, so the call is successful.

10. Please use a phone to make an incoming call, here, the SIM card number for the first channel is 15889587467, using a cell phone to dial 15889587467, the sip 500 rings, and you can get the following output from asterisk CLI:

```
-----
*CLI> -- Starting simple switch on 'DAHDI/1-1'
[Jul  1 11:42:53] NOTICE[20678]: chan_dahdi.c:8734 ss_thread: Got event 18 (Ring Begin)...
-- Executing [s@from-pstn:1] Answer("DAHDI/1-1", "") in new stack
-- Executing [s@from-pstn:2] Dial("DAHDI/1-1", "sip/500") in new stack
== Using SIP RTP CoS mark 5
-- Called 500
-- SIP/500-00000004 is ringing
-- SIP/500-00000004 answered DAHDI/1-1
-----
```

11. Plugging PSTN line into the FXO ports, customer can dial-out via FXO ports. Connecting analog phone to FXS ports, customer can use analog phone to dial-out via FXO ports or via GSM channels.

Chapter 6 Sending and Receiving SMS

There are two ways for users to send SMS by ATCOM AX-2G4A.

1. Sending SMS by asterisk CLI command directly.

In the following example, it sends a message to 13728737752 using the first channel:

```
localhost*CLI> sendsms dahdi/1 13728737752 Welcome to ATCOM
```

```
== Using SIP RTP CoS mark 5
-- Launching Sendsms(dahdi/1,13728737752>Welcome to ATCOM) on
SIP/600-0000002c
-- Launching DoSms(13728737752>Welcome to ATCOM) on DAHDI/1-1
[Apr 25 14:32:32] WARNING[22660]: chan_dahdi.c:5827 dahdi_handle_event: gsm send
sms success
-- Hungup 'DAHDI/1-1'
```

2. Sending bulk SMS

Before sending the SMS, please start Asterisk.

In /var/spool/asterisk directory, please edit a xml file like the following format, then copy the content to outgoing file, after that the SMS will be send out.

bulksms.xml

```
-----
<?xml version="1.0" encoding="UTF-8"?>
<sms>
  <receiver>15012871900</receiver>
  <receiver>13728731752</receiver>

  <channel>1</channel>

  <content>
    hello! welcom to ATCOM!
  </content>
</sms>
-----
```

Please copy the bulksms.xml content to outgoing file, run the command: **cp bulksms.xml outgoing/**

From asterisk CLI, you can get the following output, if you can see the red characters **result=1**, it means that the SMS has been sent out successfully; If you get **result=-1**, it means that the SMS fails to send out.

```
localhost*CLI>
[Sep  9 16:08:23] NOTICE[3593]: pbx_spool.c:166 apply_sms_outgoing: pbx_spool find
called name=15012871900
[Sep  9 16:08:23] NOTICE[3593]: pbx_spool.c:166 apply_sms_outgoing: pbx_spool find
called name=13728731752
--      Attempting      call      on      sms/      for      application
queuesms(dahdi/1,15012871900&13728731752,hello! welcom to ATCOM!) (Retry 1)
-- Launching queuesms(dahdi/1,15012871900&13728731752,hello! welcom to ATCOM!)
on type/data-00000001
[Sep  9 16:08:23] NOTICE[3823]: pbx_spool.c:531 attempt_thread: Call completed to sms/
-- Launching DoSms(15012871900&13728731752 hello! welcom to ATCOM!) on
DAHDI/1-1
[Sep      9   16:08:27]  NOTICE[3825]:  chan_dahdi.c:18205  sms_queue_send:
sessionid=1315555703.3 channum=1 time=2011/09/09 16:08:27 send to called=15012871900
result=1
[Sep      9   16:08:31]  NOTICE[3825]:  chan_dahdi.c:18205  sms_queue_send:
sessionid=1315555703.3 channum=1 time=2011/09/09 16:08:31 send to called=13728731752
result=1
-- Hungup 'DAHDI/1-1'
```

User can also check if the SMS is sent successfully or not by checking the `/var/log/asterisk/sms/sendsms` directory, the system will generate one log file each day for writing down if the SMS is sent successfully or not, for example, `sendsms_2011-12-02.log` is generated on Dec 02th, 2011, which writes down all the sent SMS results on Dec 02th, 2011.

The Format of the xml file

Xml file name: customer can name whatever name you want.

Receiver: add the destination phone number, one line for one destination phone number, the example above add two destination phone numbers.

Channel: choose the GSM channel by which the system send the SMS out. For one AX-2G4A, it should be 1 or 2.

Content: input or paste the SMS content that you need to send out.

3. Receiving SMS

When one SMS is received, the system will generate a file for storing the SMS, and the file is under `/var/log/asterisk/sms/recvsms` directory.

The format of the file name: `recvsms_channel_number_time_+cell phone number.log`

The format of SMS content: `channo:channel >>date time|+cell phone number| SMS content`

Chapter 7 Reference

<http://www.asteriskguru.com/>

<http://www.asterisk.org/downloads>

http://www.openippbx.org/index.php?title=Main_Page

<http://www.atcom.cn/>